SERVICE INSTRUCTIONS

Front Drive System


Before use, read these instructions carefully, and follow them for correct use.

A WARNING

- Use neutral detergent to clean the chain. Do not use alkali-based or acid based detergent such as rust cleaners as it may result in damage and/or failure of the chain.
 Use the reinforced connecting pin only for connecting the narrow type of chain.
- There are two different types of reinforced connecting pin available. Be sure to check
 the table below before selecting which pin to use. If connecting pins other than
 reinforced connecting pins are used, or if a reinforced connecting pin or tool which is
 not suitable for the type of chain is used, sufficient connection force may not be
 obtained, which could cause the chain to break or fall off.

Chain	Reinforced connecting p		Chain tool
9-speed super narrow chain such as CN-7700 / CN-HG92	6.5mm	Silver	TL-CN31/TL-CN22
8-/7-/6-speed narrow chain such as CN-HG50 / CN-IG51	7.1mm	Black	TL-CN31/TL-CN22 and TL-CN30/TL-CN21

 If it is necessary to adjust the length of the chain due to a change in the number of sprocket teeth, make the cut at some other place than the place where the chain has been joined using a reinforced connecting pin or an end pin. The chain will be damaged if it is cut at a place where it has been joined with a reinforced connecting pin or an end pin.



 Obtain, read and carefully service instructions when installing parts. A loose, worn, or damaged parts may cause injury to the rider. We strongly recommend that only genuine Shimano replacement parts be used.

• Be sure to use only the Shimano IG chain with the IG front chainwheel. The HG or UG type of chain cannot be used.

Note

- Apply grease to the bottom bracket before installing it.
- For smooth operation, use the specified outer casing and the bottom bracket cable guide.
- This front derailleur is for triple front chainwheel use only. It cannot be used with the double front chainwheel, as the shifting points do not match.
- When installing the top route type, choose a frame that has three outer casing holders as shown in the illustration at right.
- Use an outer casing which still has some length to spare even when the handlebars are turned all the way to both sides. Furthermore, check that the shifting lever does not touch the bicycle frame when the handlebars are turned all the way.
- Grease the inner cable and the inside of the outer casing before use to ensure that they slide properly.
 Operation of the layer whether the slide properly.
- Operation of the levers related to gear shifting should be made only when the front chainwheel is turning.
 For maximum performance we had be
- For maximum performance we highly recommend Shimano lubricants and maintenance products.
 For any questions recording wetter to the first set of the fi
- For any questions regarding methods of installation, adjustment, maintenance or operation, please contact a professional bicycle dealer.





In order to realize the best performance, we recommend that the following combination be used.

Series	ACERA-X		
EZ-fire Plus	ST-EF33		
Outer casing	SP40		
Front derailleur	FD-M330 / FD-M330-E		
Front chainwheel	FC-MC20 / FC-MC19		
Bottom bracket	BB-LP27 / BB-LP27-E		
Chain	CN-IG51 / CN-IG31		
Bottom bracket cable guide	SM-SP18 / SM-BT18 SM-SP17 / SM-BT17		

Specifications

Front Derailleur

Model number	FD-M330	FD-M330-E	
Bottom bracket	BB-LP27	BB-LP27-E	
Normal type	0	0	
Top route type	0	0	
Front chainwheel tooth difference	20T	20T	
Min. difference between top and intermediate	10T	10T	
Front derailleur installation band diameter	S, M	S, M	L
Stroke (A-A')	38 - 58 mm	38 - 58 mm	
Chainstay angle (α)	63° - 66°	66° - 69°	
Applicable chain line	47.5 mm, 50 mm	47.5 mm, 50 mm	50 mm
Installation band diameters: S (28.6 mm).	Stroke	Chainstay	

S (28.6 mm), M (31.8 mm), L (34.9 mm)




Chainwheel

Model number	FC-MC20	FC-MC19	
Chainwheel tooth combination	42T - 32T - 22T		
Bolt circle diameter	104 mm / 64 mm	Riveted	
Crank arm length (mm)	170 mm, 175 mm		
Pedal thread dimensions	BC 9/16" X 20 T.P.I.		

Bottom Bracket


Model number	BB-LP27		BB-LP27-E	
Front derailleur	FD-M330		FD-M330-E	
Stamped marking	MM110	LL113	MM110	LL113
Spindle length	110 mm	113 mm	110 mm	113 mm
Chain line	47.5 mm	50.0 mm	47.5 mm	50.0 mm
Thread dimensions	BC1.37" X 24 T.P.I. (68, 73 mm) M 36" X 24 T.P.I. (70 mm)		BC1.37" X 24 T.P.I. (68 mm)	BC1.37" X 24 T.P.I. (73 mm) 36" X 24 T.P.I. (70 mm)

Installation of the Front Derailleur, Bottom Bracket and Front Chainwheel





50 - 70 Nm {435 - 608 in. lbs.} Front chainwheel tightening torque: 35 - 50 Nm {305 - 435 in. lbs.}

Adjust and then install the front derailleur as shown in the illustration. Do not remove the Pro-Set alignment block at this time.




guide outer plate should be directly above and parallel to the largest chainring. Secure using a 5 mm Allen key.





< FD-M330-E >




Installaation of the chainrings


Be sure to use the following combination for the tooth configuration.

M 42-32-22 (FC-MC20)

Position so that, when looking from the rear side, the M- marks come to the positions as shown in the illustration. and so that the chain-drop prevention pin is directly behind the Projecting parts . crank arm. ţn, Surger . . 1 Marks Chain-drop prevention pin Crank arm U n 0

The features of the SIS will not be obtained if the chainrings are installed in the incorrect position, or if a chainring with a mark other than M- \Box is being combined. Therefore, be sure to install them in the correct position.






SIS adjustment

Be sure to follow the sequence described below.

- 1. Low adjustment
 - First remove the Pro-Set alignment block.


Next, set so that the clearance between the chain guide inner plate and the chain is 0-0.5 mm.




2. Connection and securing the inner cable

Remove the two indicator fixing screws which are securing the indicator, and then remove the indicator unit as shown in the illustration.


Operate lever (B) two or more times to set the lever to the lowest position. Pass the inner cable through the lever hole and hook it onto the lever, and then secure the indicator unit with the two indicator fixing screws.



Pull



4. Adjustment of the intermediate chainring When carrying out adjustment, set the chain to the largest sprocket, and at the front, set the chain to the intermediate chainring. Adjust using the outer casing adjustment barrel so that the clearance between the chain guide inner plate and the chain is 0-0.5 mm.



Inserting the inner cable

Insert the inner cable into the outer casing from the end with the marking on it. Apply grease from the end with the marking in order to maintain cable operating efficiency.



Cutting the outer casing

When cutting the outer casing, cut the opposite end to the end with the marking. After cutting the outer casing, make

the end round so that the inside of the hole has a uniform diameter.



Attach the same outer end cap to the cut end of the outer casing.



5. Troubleshooting chart


After completion of steps 1 - 4, move the shifting lever to check the shifting. (This also applies if shifting becomes difficult during use.)

• ,	
If the chain falls to the crank side.	Tighten the top adjustment screw clockwise (about 1/4 turn).
If shifting is difficult from the intermediate chainring to the largest chainring.	Loosen the top adjustment screw counterclockwise (about 1/8 turn).
If shifting is difficult from the intermediate chainring to the smallest chainring.	Loosen the low adjustment screw counterclockwise (about 1/4 turn).
If there is interference between the chain and the front derailleur inner plate at the largest chainring.	Tighten the top adjustment screw clockwise (about 1/8 turn).
If there is interference between the chain and the front derailleur outer plate at the largest chainring.	Loosen the top adjustment screw counterclockwise (about 1/8 turn).
If the intermediate chainring is skipped when shifting from the largest chainring.	Loosen the outer casing adjustment barrel counterclockwise (1 or 2 turns).
If there is interference between the chain and front derailleur inner plate when the rear sprocket is shifted to the largest sprocket when the chainwheel is at the intermediate chainring position.	Tighten the outer casing adjustment barrel clockwise (1 or 2 turns).
If the chain falls to the bottom bracket side.	Tighten the low adjustment screw clockwise (about 1/2 turn).

Gear shifting operation

Both lever (A) and lever (B) always return to the initial position when they are released after shifting. When operating one of the levers, always be sure to turn the crank arm at the same time. To shift from a small chainring to a larger chainring When lever (A) is pressed once, there is a shift of one step from a small chainring to a larger chainring. Example: from intermediate chainring to largest chainring. Lever (A) initial position To shift from a large chainring to a smaller chainring When lever (B) is pressed once, there is a shift of one step from a large chainring to

a smaller chainring. Example: from largest chainring to intermediate chainring.



This service instruction explains how to use and maintain the Shimano bicycle parts which have been used on your new bicycle. For any questions regarding your bicycle or other matters which are not related to Shimano parts, please contact the place of purchase or the bicycle manufacturer.

SHIMANO

SHIMANO AMERICAN CORPORATION One Holland Irvine CA 92618 U.S.A. Phone 949-951-5003 SHIMANO EUROPA

Industrieweg 24 NL-8071 CT Nunspeet Holland Phone 31-341-272222 SHIMANO INC.

77 Oimatsu-cho 3-cho Sakai Osaka 590-8577 Japan Phone 072-223-3243

Please note: specifications are subject to change for improvement without notice. (English) © Jun. 2000 by Shimano Inc. XBC SZK Printed in Malaysia

