

A-1



TOOL

1. Hex Key
2. Screw driver
3. Hex Wrench
4. 20mm wrench
5. 22mm wrench
6. C Clamp

A-2



Use screwdriver turning counter clock-wise to loosen the bolt of the rebound knob.

A-3



Take out the Top Cap (rebound damper cartridge)

A-7



Use 22mm Hex Wrench by turning counter clock-wise to loosen the top cap.

A-8



Remove the rebound damper cartridge.

A-9



Use 20mm Hex Wrench by turning counter clock-wise to loosen the top cap of spring side.

A-4



1. Rebound Knob
2. Screw
3. Detent spring
4. Detent ball

A-5



Use 4mm Hex Key by turning counter clock-wise to loosen the bolt on the both bottom side of the fork.

A-6



Separate the Crown assy. From the outer casting.

A-10



Remove the Spring Top cap rod from spring side.

A-11



Took out the spring.

A-12



Remove the Bumper from the bottom of the Crown assembly.

A-13



After remove the bumper then you can took out the compression rod from top of inner leg.

A-14



Use C clamp to remove the C-clip.

A-15



Took out the washer.

A-16



There is one more C-Clip inside the inner leg, use C clamp to took it out.

A-17



This is the photos after disassembly the fork.

RST 2008 Assemble R1

B-1



This is the photo before assemble.

B-2



Installed the C-clip into the clip groove inside of the legs.

B-3



Install the washer

RST 2008 Assemble R1

B-7



Install the spring.

B-8



Install the spring top cap rod.

B-9



Use a 20mm Hex Wrench by turning clock-wise to tighten the spring top cap.

RST 2008 Assemble R1

B-4



Install the 2nd C-clip into the clip groove.

B-5



Install the compression rod from the top of the leg.

RST 2008 Assemble R1

B-10



Install the rebound damper cartridge into the legs.

B-11



Use a 22mm Hex wrench to tighten the damper top cap by turning clock-wise.

B-6



Install the bumper.

B-12



Install the crown assembly into the casting.

RST
2008

Assemble
R1

B-13



Use 4mm Hex Key to tighten the bolt on the bottom of the fork .
(For both side)

B-14



- 1. Rebound knob
- 2. Screw
- 3. Detent spring
- 4. Detent ball

B-15



Install the detent spring and spring ball into the top cap of the rebound cartridge.

RST
2008

Assemble
R1

B-16



Tighten the screw on the rebound knob.

RST
2008

Assemble
R1

RST
2008

Assemble
R1

B-18

B-24